# Link Hand-Held Hopper Walker Remote Control to Base

There are three types of remotes currently in circulation for the “Amber Base” style Hopper Walker. Use the directions appropriate for the following:

- 3-LIGHT Remote.
- 4-LIGHT GEN-1 (RR crossing light pattern when holding ON button during power up.)
- 4-LIGHT GEN-2 (POWER & ERR illuminate when holding ON button during power up.)

Video examples available on YouTube. Search YouTube for Hopper Walker Remote.

---

## Link 4-LIGHT GEN-1 Remote

Identify the remote by pressing the ON button for 2 seconds when powering up.

*When powering the remote, press and hold the ON button for a couple of seconds. If the indicator lights flash between the top and bottom two lights, use the following instructions:*

1. Power off Base by pressing the red STOP button by the joystick.
2. Power off remote.
3. At the same time, press and hold the ON and OFF buttons on the remote until the top two lights are on.
4. Release the ON and OFF buttons.
5. Press and hold the ON button until the top light flashes.
6. While still holding down the ON button on the remote, twist the red STOP button to power on the base unit.
7. When all four lights on the remote are on, release the ON button.
8. The LINK light on the REMOTE and BASE should be flashing, indicating they are ready to use.

---

## Link 4-LIGHT GEN-2 Remote

Identify the remote by pressing the ON button for 2 seconds when powering up.

*When powering the remote, press and hold the ON button for a couple of seconds. If the ERR light & POWER light illuminate, use the following instructions:*

1. Power off Base by pressing the red STOP button by the joystick.
2. Power off remote.
3. At the same time, press and release the ON and OFF buttons on the remote.
4. Immediately press and hold the ON button.
5. While still holding down the ON button on the remote, twist the red STOP button to power on the base unit.
6. Once the base unit is powered up, release the ON button on the remote.
7. The LINK light on the REMOTE and BASE should be flashing, indicating they are ready to use.

---

Remotes can only link to one Hopper Walker base at a time.

**Note: This process only works for the “Amber Base” style control box Hopper Walker. Older style Hopper Walkers, 2008 and earlier, require a crystal and specific program for the remote. Please call Hopper Walker at 800-478-7801 for assistance.*

Ver 2025.102825

# Link Hand-Held Hopper Walker Remote Control to Base

There are three types of remotes currently in circulation for the “Amber Base” style Hopper Walker.

Use the directions appropriate for the following:

- 3-LIGHT Remote.
- 4-LIGHT GEN-1 (RR crossing light pattern when holding ON button during power up.)
- 4-LIGHT GEN-2 (POWER & ERR illuminate when holding ON button during power up.)

Video examples available on YouTube. Search YouTube for Hopper Walker Remote.

---

## Link 3 light Hopper Walker remote to base

1. Power off Base by pressing the red STOP button by the joystick.
2. Power off remote.
3. At the same time, press and release the ON and OFF buttons on the remote.
4. Immediately press and hold the ON button until the middle (link) light stops flashing.
5. While still holding down the ON button on the remote, twist the red STOP button to power on the base unit.
6. Once the base unit is powered up, release the ON button on the remote.
7. The LINK light on the REMOTE and BASE should be flashing, indicating they are ready to use.

---

Remotes can only link to one Hopper Walker base at a time.

**Note: This process only works for the “Amber Base” style control box Hopper Walker. Older style Hopper Walkers, 2008 and earlier, require a crystal and specific program for the remote. Please call Hopper Walker at 800-478-7801 for assistance.*