Converting a Hopper Walker 3 Hole Box to a 2 Hole Box with a new Joystick



BLACK WIRE FROM STOP SWITCH AND BLACK JUMPER



MOTOR WIRES



The blue wire is connected to the wire on the rectifier opposite the “+” sign.

DO NOT OVERTIGHTEN THE SCREWS IN THE JOYSTICK; YOU WILL DAMAGE THE SWITCHES!!

Make sure joystick handle is attached to switch blocks before applying powering; if not, you will blow a fuse!