Old Style Hopper Walker w/ New Style Joystick



DO NOT OVERTIGHTEN THE SCREWS IN THE JOYSTICK; YOU WILL DAMAGE THE SWITCHES



Make sure joystick handle is attached to switch blocks before applying powering; if not, you will blow a fuse!